



苏州市昆腾电子有限公司  
SUZHOU CITY KUNTENG ELECTRONIC CO., LTD



# 用户手册

User Manual

---

KT-INS01 E-Bike Special Meter

WWW.SZKTDZ.COM

## Contents

Preface.....	4
Outlook and Size.....	4
Meter Dimension .....	4
Main Material and Color.....	5
Wiring Schematic.....	5
Installation Instruction.....	5
Physical installation icon.....	6
Function Overview.....	6
Display Content.....	6
Normal Operation.....	7
On/Off.....	7
Display Interface.....	7
Display of Turned on Throttle.....	9
Display of Pas .....	9
PAS Ratio (or Throttle) Gear Switch.....	9
Push Function.....	10
Cruise Function.....	10
Turn On/Off Backlight.....	11
Startup Backlights and Headlights.....	11
Battery Capacity Indicator.....	12
Single Data Clearing.....	13
Automatically Prompt Interface.....	13
<i>Error Code Display</i> .....	13
User Setting Project.....	14
General Project Setting.....	14
Maximum Trip Speed.....	14
Wheel Diameter.....	15
Metric and Imperial Units.....	15



P Parameter Setting.....	16
P1 Motor Characteristic Parameter Setting .....	16
P2 Wheel Speed Pulse Signal Setting .....	17
P3 Power Assist Control Mode Setting .....	18
P4 Throttle Startup Setting .....	18
P5 Power Monitoring Setting .....	19
C Parameter Setting .....	20
C1 Power-Assist Sensor and Parameter Select Setting.....	20
C2 Motor Phase Classification Coding Setting .....	21
C3 Power Assist Ratio Gear Initialization Setting.....	21
C4 Throttle Function Setting .....	22
C5 Controller Maximum Current Adjustment Setting .....	24
C6 Backlight Brightness Adjustment Setting .....	25
C7 Cruise Function Setting .....	26
C8 Not Identified.....	26
C9 Power-on Password Setting .....	27
C10 Automatic Restore Default Setting .....	28
C11 Attribute Selection Setting .....	29
C12 Controller Minimum Voltage Adjustment Setting .....	30
C13 ABS brakes of the controller and parameters of anti-charge control Setting .....	32
C14 Power-assist Tuning Parameters Setting .....	33
C15 Push-assist Speed Parameters Setting.....	33
L Parameter Setting .....	34
L1 Parameters Setting .....	34
L2 Parameters Setting .....	35
L3 Parameters Setting.....	36
L4 Parameters Setting.....	36
Exit Parameter Setting.....	37
Parameter Copy .....	37
User Setting Note .....	39

Version Information..... 39

The illustrated manual will help you understand and be familiar with the meter function, guiding you on how to operate the meter, how to set the project parameters, how to achieve the best match of the three as motor, controller and meter to improve electronic control performance of the electric motor. This manual covers installation, operation, parameter setting of the meter and how to use it properly, which help you resolve the problems appeared in practical use.

### Outlook and Size

#### ○ Meter Dimension




**Meter Dimension**

○ **Main Material and Color**

PC material is mainly used for KT-INS01 meter, and the housing color is black.

○ **Wiring Schematic**



**Installation Instruction**

Embed the instrument main body into the frame of the electric vehicle, adjusting perspective. In the case that the vehicle is power off, the meter connectors are in plug connection to corresponding controller connectors. Turn on the power, electric vehicle and meter will be under normal operation, the meter installation is finished. The protection film on meter display panel should be torn.






○ **Physical installation icon**



**Function Overview**


KT-INS01 meter provide you with a variety of functions such as vehicle controls and

vehicle status digitized displays to meet the trip demands.

- ◇ Trip speed display (with displays of real-time speed (KM/H or MPH) and a single maximum speed (MXS));
- ◇ Trip distance display (with displays of a single trip distance (DST) and total trip distance (ODO));
- ◇ Display of turned on throttle (**Throttle**) ;
- ◇ Power assistant ratio (or throttle) gear (**Assist**) switch;
- ◇ 6KM/H power assistant push (  ) function;
- ◇ Cruise function (**Cruise**  );
- ◇ Battery capacity indicator (  );
- ◇ Real-time battery voltage (**VOL**) display;
- ◇ Brake status display (  );
- ◇ Turn on backlighting and lights (  );
- ◇ Data clearing;
- ◇ Fault code display;
- ◇ User parameter setting;
- ◇ 24V, 36V, 48V supply voltage can automatic identification and be compatible.



## Display Content

The display content is shown as follow.





## Normal Operation

### ○ On/Off


Hold  button (SW) long, the meter is powered on and into normal operation, and it provides the controller with power supply. Under normal operating status, hold  button (SW) long, the meter is powered off, meanwhile to shutdown the power supply of controllers. **When the vehicle is stopped and without any button operation on the meter for five minutes, the meter will automatically shut down, and the power supply of the electric vehicle will be powered off.** In power off mode, the power consumption of the meter and controller is zero.

### ○ Display Interface

Hold  button (SW) long, the meter is startup to enter display 1.



Display 1

In display 1, hold  button (SW) shortly to enter display 2.



Display 2

**In the riding mode within 5 seconds, display 2 automatically jump to display 1**



Display 3

In display 2 or display 3, hold  button (SW) shortly again to enter display 3.

**In each display interface, if you hold  button (SW) long, the meter will be**

powered-off together with that of the controller.

#### ○ Display of Turned on Throttle

Rotate the throttle control handle under normal operating of the meter, the display interface shows the logo of turned-on throttle, see the Figure below.






#### ○ Display of Turned on Pass

The logo of pas will flash, under the normal riding mode, when the pas turned on






#### ○ PAS Ratio (or throttle) Gear Switch


Under normal operation, hold  button (UP) or  button (DOWN) to switch the power assist ratio (or Throttle) gear (Assist), changing motor output power. Switching range is 0-5 gear (this can also be configured according to the customer requirements), gear 1 is for the lowest power, and gear 5 is for the highest power.




At every startup, the meter will automatically restore gear (this can also be configured as required by users) when it was at last shut down. When the power assist ratio is gear 0 zero, there's no power assist function.


#### ○ Power Assistant Push Function

Users can use 6KM/H power assist function when pushing vehicles. Hold  button (**DOWN**), the meter assist function logo () flashes, the vehicle drives at the speed of no more than 6km/h. Release  button (**DOWN**), the assist function will be revoked.







#### ○ Cruise Function

When C7 parameter setting is 1, the meter turns on cruise function, hold  button (**DOWN**) long to enter the cruise status when the vehicle speed is more than 7 km/h, and the cruise function logo (**Cruise**) lights. Brake or hold any button to revoke cruise function.





### ○ Startup Backlights and Headlights

Hold  button (UP) long, the meter turns on the backlights as well as the vehicle headlights (**the Controller should have headlights driving and output functions**), meter backlighting and vehicle lights power logo (  ) light, hold  button (UP) long again to turn off backlights and vehicle headlights.



### ○ Brake status display


Under normal operation, vehicle brake, brake status indicator display (  ), as shown in the figure.



○ **Battery Capacity Indicator**

The meter can automatically identify 24V, 36V, 48V battery capacities when it is supporting use with the specified controller. When the battery capacity is over 70%, the four power displays of the meter are lit, when the battery capacities drop, the four power displays are off in order, when the power capacity is less than 15%, the four power displays are totally turned off.




When the controller is power off due to voltage shortage, the power display frame flashes, indicating the vehicle has been in voltage shortage and waiting for shutdown currently.




Voltage shortage flashes

Battery capacity indicator

### ○ Single Data Clearing

5 seconds after the meter is powered on, at display 1, hold both the  button (UP) and the  button (DOWN) simultaneously for about 2 seconds, the single trip time (TM) and single trip distance (DST) flicker, then hold  button shortly (SW), the record contents of both will be cleared.



**Under the status of data flashing, if there were no operations on the data within 5 seconds, the meter will automatically return to display1 after 5 seconds, and the original record content will be saved.**

### ○ Automatically Prompt Interface

Error Code Display:

When the electronic control system of the electric vehicle fails, and the meter will automatically display (flicker) fault code. You can't exit the fault code display only the fault is removed.



## Error Code &amp; Definition Table:

Error Code	Definition
Motor position sensor fault!	illegal signal for hall sensor
Motor or controller short circuit fault!	there is a short-circuit fault occur
Throttle fault!	illegal signal for throttle




### User Setting Project

KT-INS01 meter user setting project:


- ◇ General project setting
- ◇ P parameter setting
- ◇ C parameter setting
- ◇ L parameter setting

### General Project Setting




#### ○ Maximum Trip Speed

Max speed setting LIM, hold  button shortly (SW) when the cursor before LIM, the value flash. To setting max speed by press  button (UP) or  button (DOWN). **The default value of max speed was set according to user's requirement.** The motor will stop, when the speed exceeds the max speed which has been set before


▶ LIM : 25 KM/H
DIM : 26"
UNT : 0
P1 : 87
P2 : 1
P3 : 1
P4 : 0
P5 : 12
C1 : 2
C2 : 0
C3 : 8
NEXT ▶

After finishing the maximum riding speed setting, press  button shortly (SW) , to return to parameter setting interface.




### ○ Wheel Diameter

Under parameter setting interface, move cursor to DIM and press  button shortly (SW), the value flashes. Press  button (UP) or  button (DOWN) to choose the corresponding wheel diameter specification to a selected vehicle. The selection range of wheel diameter specifications are 16 species such as 5,6,8,10,12,14,16,18,20,23,24,26,27.5,700c, 28 and 29 inches.

LIM : 25 KM/H
▶ DIM : 26"
UNT : 0
P1 : 87
P2 : 1
P3 : 1
P4 : 0
P5 : 12
C1 : 2
C2 : 0
C3 : 8
NEXT ▶

After finishing the wheel diameter setting, press  button (SW) shortly to return to parameter setting interface.


### ○ Metric and Imperial Units

Under parameter setting interface, move cursor to UNT and press  button shortly (SW), the value flashes. Press  button (UP) or  button (DOWN) shortly to choose within the range of 0-3.

LIM : 25 KM/H
DIM : 26"
▶ UNT : 0
P1 : 87
P2 : 1
P3 : 1
P4 : 0
P5 : 12
C1 : 2
C2 : 0
C3 : 8
NEXT ▶




Definition Table of Metric/Imperial Units:

Code	Speed	Mileage
0	Km/h	Km
1	MPH	Mil
2	Km/h	Km
3	MPH	Mil


After finishing the metric/imperial units setting, press  button shortly (SW) to return to parameter setting interface.

### P Parameter Setting


P1 is motor characteristic parameter setting,  $P1 = \text{motor gear reduction ratio} \times \text{number of motor magnet pieces}$ , just rounding if there's any decimal.

Under parameter setting interface, move cursor to P1 and press  button shortly (SW), the value flashes. press button (DOWN)  button (UP) or  button (DOWN) for selection within the range of 1-255.



LIM : 25 KM/H
DIM : 26"
UNT : 0
▶ P1 : 87
P2 : 1
P3 : 1
P4 : 0
P5 : 12
C1 : 2
C2 : 0
C3 : 8
NEXT ▶


After finishing P1 parameter setting, you can press  button to return to parameter setting interface.

#### ○ P2 Wheel Speed Pulse Signal Setting

Under parameter setting interface, move cursor to P2 and press  button shortly (SW), the value flashes.

LIM : 25 KM/H
DIM : 26"
UNT : 0
P1 : 87
▶ P2 : 1
P3 : 1
P4 : 0
P5 : 12
C1 : 2
C2 : 0
C3 : 8
NEXT ▶


P2 is wheel speed pulse signal setting, if wheel generated 1 pulse signal by a revolution, P2 should be set as 1. If wheel generated 6 pulse signals by a revolution, P2 should be set as 6. If users didn't configure the pulse signal system, and then P2 parameter setting can be 0. The setting range of P2 should be between 0-6, hold  button (UP) shortly or  button (DOWN) for selection.

After finishing P2 parameter setting, press  button (SW) to return the parameter setting interface.



**Please Note:** when P2 parameter is set to be 0, for the built-in clutch motor, there will


be the following defects, when the internal motor rotors stop or the internal rotor speed is lower than the outer rotor speed, then the speed displayed on the meter is inaccurate!

### ○ P3 Power Assist Control Mode Setting


Under parameter setting interface, move cursor to P3 and press  button shortly (SW), the value flashes.

LIM : 25 KM/H
DIM : 26"
UNT : 0
P1 : 87
P2 : 1
▶ P3 : 1
P4 : 0
P5 : 12
C1 : 2
C2 : 0
C3 : 8
NEXT ▶



P3 is power assist control mode setting, when P3 parameter setting is 1, power assist control mode is gear 5 of "imitation torque control" mode, when P3 parameter setting is 0, power assist control mode is gear 5 of "speed control" mode. P3 parameter needs to be determined according to the distributed function of the controller, its setting range is 0 or 1, press  button (UP) or  button (DOWN) for selection.


After finishing P3 parameter setting, press  button (SW) to return to the parameter setting interface.

### ○ P4 Throttle Startup Setting


Under parameter setting interface, move cursor to P4 and press  button shortly (SW), the value flashes.

LIM : 25 KM/H
DIM : 26"
UNT : 0
P1 : 87
P2 : 1
P3 : 1
▶ P4 : 0
P5 : 12
C1 : 2
C2 : 0
C3 : 8
NEXT ▶

P4 is throttle startup setting, when P4 setting is 1, indicating the throttle is under "non-zero startup" mode, namely, the throttle can be effective only after startup the foot power assist. When P4 setting is 0, indicating the throttle is under "zero startup" mode, the motor can be startup by the throttle directly. P4 setting range is 0 or 1, press  button (UP) or  button (DOWN) for selection.



After finishing P4 parameter setting, press  button (SW) to return to parameter setting interface.


#### ○ P5 Power Monitoring Setting

Under parameter setting interface, move cursor to P5 and press  button shortly (SW), the value flashes.

LIM : 25 KM/H
DIM : 26"
UNT : 0
P1 : 87
P2 : 1
P3 : 1
P4 : 0
▶ P5 : 12
C1 : 2
C2 : 0
C3 : 8
NEXT ▶


P5 is power monitoring setting. When P5 equals to a specified parameter, the power monitoring is the "smart power" mode (this parameter is determined by the battery characteristics, ordinary 24V lithium is generally is 4-11, 36V lithium is between 5\_15, For


48V batteries, set the value of P5 parameter between 6 and 17; for 52V batteries, set it between 7 and 18; If batteries is 60V and above, adjust the appropriate P5 parameter according to the actual battery voltage). P5 setting ranges from 1-60, press  button (UP) or  button (DOWN) for selection. P5 parameter setting method is the same to that of P2.



After finishing P5 parameter setting, press  button (SW) to return parameter setting interface.

### C Parameter Setting

#### ○ C1 Power-Assist Sensor and Parameter Select Setting

Under parameter setting interface, move cursor to C1 and press  button shortly (SW), and the value flashes.



C1 is power-assist sensor and parameter select setting, its definition is shown in following table. C1 setting ranges between 0-7, press  button (UP) or  button (DOWN) for selection.

C1 parameter definition table:


KUNTENG power assist sensors	C1 value	Start Sensitivity	KUNTENG V12 power assist sensors	C1 value	Start Sensitivity
Forward 5 Signal	00	Standard	Reverse 6 Signal	05	Standard
	01	Lower		06	Lower
	02	Lowest		07	Lowest
Forward 8 Signal	00	Higher	Reverse 10 Signal	05	Higher

	01	Standard		06	Standard
	02	Lower		07	Lower
Forward 10 Signal	00	Highest	Reverse 12 Signal	05	Highest
	01	Higher		06	Higher
	02	Standard		07	Standard




Forward power sensor signal waveforms



Reverse power sensor signal waveforms


After finishing C1 parameter setting, press  button (SW) to return to parameter setting interface.

### ○ C2 Motor Phase Classification Coding Setting


Under parameter setting interface, move cursor to C2 and press  button shortly (SW), the value flashes.

LIM : 25 KM/H
DIM : 26"
UNT : 0
P1 : 87
P2 : 1
P3 : 1
P4 : 0
P5 : 12
C1 : 2
▶ C2 : 0
C3 : 8
NEXT ▶

C2 is motor phase classification coding setting, it is served as identification parameter of different phases of the motor when using sine wave drive and the default value is 0. When C2 setting is 0, indicating that the used Quantum motor phase is an ordinary one. When the setting is a certain value, indicating a particular motor phase is used. C2 setting range is 0-1, press  button (UP) or  button (DOWN) for selection.

After finishing C2 parameter setting, press  button (SW) to return to parameter setting interface.

### ○ C3 Power Assist Ratio Gear Initialization Setting

Under parameter setting interface, move cursor to C3 and press  button shortly (SW), the value flashes.


LIM : 25 KM/H
DIM : 26"
UNT : 0
P1 : 87
P2 : 1
P3 : 1
P4 : 0
P5 : 12
C1 : 2
C2 : 0
▶ C3 : 8
NEXT →

Press  button (UP) or  button (DOWN) for selection C3 parameter values.


The factory default is 8.

C3 parameter values:



C3	Parameter value meaning
0	The meter is powered on and the power assist ratio is at gear 0.
1	The meter is powered on and the power assist ratio is at gear 1.
2	The meter is powered on and the power assist ratio is at gear 2.
3	The meter is powered on and the power assist ratio is at gear 3.
4	The meter is powered on and the power assist ratio is at gear 4.
5	The meter is powered on and the power assist ratio is at gear 5.
6&7	Retain
8	Each startup will automatically restore the gear shutdown last time.

After finishing C3 parameter setting, press  button (SW) to return parameter setting interface.

#### ○ C4 Throttle Function Setting



Under parameter setting interface, move cursor to C4 and press  button shortly (SW), the value flashes.


▶ C4 : 0
C5 : 10
C6 : 3
C7 : 0
C8 : 0
C9 : 0
C10 : N
C11 : 0
C12 : 4
C13 : 0
C14 : 2
NEXT ▶


C4 is throttle function setting, the setting range is 0-4, press  button (UP) or  button (DOWN) for selection.


C4 parameter definition table:

C4 value	P4=0	P4=1
0	zero startup throttle	Non-zero startup throttle
1	Zero startup, throttle speed limit is 6KM/H	Before power assist, the throttle speed limit is 6KM/H, after power assist, throttle is full speed.
2	Zero startup, throttle speed limit is specified	Non-zero startup, throttle is specified speed limit.
3	Zero startup, Zero gear effectively	Before power assist, the throttle speed limit is 6KM/h, after power assist, throttle is full speed. Stop power assist, return the throttle speed limit is 6KM/H.
4	Throttle gears is distinguished according to the display meter.	Non-zero startup throttle, Throttle gears is distinguished according to the display meter.
5	Retain	Retain


When C4 = 2 is confirmed, "specified speed limit value of throttle " flashes, press  (UP) button or  (DOWN) button for short to make selection, and the default value is 20.

When C4 = 4 is confirmed, the "percentage value of the first gear speed accounts for its full speed" of the power assist gear flashes, press  (UP) button or



 (DOWN) button for short to make selection, and the default value is 50%. The percentage values of other gears divide automatically in equal.

After finishing C4 parameter setting, press  button (SW) to return to parameter setting interface.

#### ○ C5 Controller Maximum Current Adjustment Setting

Under parameter setting interface, move cursor to C5 and press  button shortly (SW), the value flashes.

▶ C4 : 0
C5 : 10
C6 : 3
C7 : 0
C8 : 0
C9 : 0
C10 : N
C11 : 0
C12 : 4
C13 : 0
C14 : 2
NEXT ▶


C5 is controller maximum operating current adjustment setting (tiny-adjustment of limit current value), the default value is 10, setting range is 0-10, press  button (UP) or  button (DOWN) for selection.

C5 parameter definition table:


C5 value	Maximum current value(A)
00	Three level slow start/ Maximum current value
01	Two level slow start/ Maximum current value
02	One level slow start/ Maximum current value
03	Maximum current value ÷ 2.00
04	Maximum current value ÷ 1.50
05	Maximum current value ÷ 1.33
06	Maximum current value ÷ 1.25
07	Maximum current value ÷ 1.20

08	Maximum current value ÷ 1.15
09	Maximum current value ÷ 1.10
10	Maximum current value



When C5 setting is 10, maximum current value is controller maximum operating current value (ie, limit current value); when setting is 9, maximum current value divided by 1.10, when setting is 8, maximum current value divided by 1.15 and so on.

After finishing C5 parameter setting, press  button (SW) to return to parameter setting interface.

### ○ C6 Backlight Brightness Adjustment Setting


Under parameter setting interface, move cursor to C6 and press  button shortly (SW), the value flashes.

C4 : 0
C5 : 10
▶ C6 : 3
C7 : 0
C8 : 0
C9 : 0
C10 : N
C11 : 0
C12 : 4
C13 : 0
C14 : 2
NEXT ▶


C6 is the meter backlight brightness adjustment setting, the default value is 3, and setting range is 1-5, press  button (UP) or  button (DOWN) for selection.

C6 parameter definition table:



C6 value	Backlight brightness
1	Dimmest
2	Darker
3	Standard
4	Brighter
5	Brightest

After finishing C6 parameter setting, press  button (SW) to return to parameter setting interface.

### ○ C7 Cruise Function Setting


Under parameter setting interface, move cursor to C7 and press  button shortly (SW), the value flashes.

C4 : 0
C5 : 10
C6 : 3
▶C7 : 0
C8 : 0
C9 : 0
C10 : N
C11 : 0
C12 : 4
C13 : 0
C14 : 2
NEXT ▶

C7 is cruise function setting, the setting range is 0 or 1, press  button (UP) or  button (DOWN) for selection.


C7 parameter definition table:


C7 value	Cruise function
0	Off
1	On

After finishing C7 parameter setting, press  button (SW) to save return to parameter setting interface.


### ○ C8 Not Identified


Enter C8 parameter setting interface C8=0





After finishing C8 parameter setting, press  button (SW) to return to parameter setting interface.

○ **C9 Power-on Password Setting**

Under parameter setting interface, move cursor to C9 and press  button shortly (SW), the value flashes.






C9 is meter power-on password setting, the default value is 0, press  button (UP) or  button (DOWN) for selection.

C9 parameter definition table:


C9 value	Startup password setting
0	Function off
1	Function on

When C9 setting is 1, indicating that the password function is startup, and then enter the password settings interface, three password setting columns flash.






The password setting is done sequentially from left to right, press  button to confirm after each setting and enter next setting. Password setting range is 000-999, press  button (**UP**) or  button (**DOWN**) for selection.



**Please note:** If you forget your password, the parameters can only be copied (see parameter copy) by data source meter prior to be decoded.

After finishing C9 parameter setting, press  button (**SW**) to return to parameter setting interface.

#### ○ C10 Automatic Restore Default Setting


Under parameter setting interface, move cursor to C10 and press  button shortly (**SW**), and the value flashes.


C4 : 0
C5 : 10
C6 : 3
C7 : 0
C8 : 0
C9 : 0
 C10 : N
C11 : 0
C12 : 4
C13 : 0
C14 : 2
NEXT 

C10 is automatic restore factory settings, the default is N, and the setting can be N, or Y, press  button (**UP**) or  button (**DOWN**) for selection.


C10 parameter definition table:

C10 value	Restore default setting
N	Function off
Y	Function on



When the meter is needed to restore default setting, C10 selects Y, hold  button long for about 2 seconds, all parameters restore default settings and exit setting environment, and then return to the display1.

After finishing C10 parameter setting, press  button (SW) to return to parameter setting interface.

### ○ C11 Attribute Selection Setting

Under parameter setting interface, move cursor to C11 and press  button shortly (SW), and the value flashes.


C4 : 0
C5 : 10
C6 : 3
C7 : 0
C8 : 0
C9 : 0
C10 : N
▶C11 : 0
C12 : 4
C13 : 0
C14 : 2
NEXT ▶

C11 is meter attribute selection setting, the setting range is 0-2, press  button (UP) or  button (DOWN) for selection.


C11 parameter definition table:

C11 value	Meter Attribute
0	Meter uses KT-INS01 new version of communication protocol, it is' compatible with LCD1 and LCD2.
1	Meter uses LCD1 and LCD2 old version communication protocol, it is not compatible with second-generation display.


2	As data source for copying parameters, the meter transfers data to other second-generation meters.
3	As data source for copying parameters, the meter transfers data to other third-generation meters.
4	As data source for copying parameters, the meter transfers data to other fourth-generation meters.

C11 selects 2, hold  (SW) long for about 2 seconds to exit the setting environment, and then the meter is served as data source for copying parameter (see parameter copy), there's source logo on display interface.



▶ LIM : 25 KM/H
DIM : 26"
UNT : 0
P1 : 87
P2 : 1
P3 : 1
P4 : 0
P5 : 12
C1 : 2
C2 : 0
C3 : 8
SOURCE

After finishing C11 parameter setting, press  button (SW) to return to parameter setting interface.

#### ○ C12 Controller Minimum Voltage Adjustment Setting

Under parameter setting interface, move cursor to C12 and press  button shortly (SW), and the value flashes.

C4 : 0
C5 : 10
C6 : 3
C7 : 0
C8 : 0
C9 : 0
C10 : N
C11 : 0
▶C12 : 4
C13 : 0
C14 : 2
NEXT ▶


C12 is controller minimum operating voltage adjustment setting (tiny adjustment of voltage shortage), the default value is 4, and the setting range is 0-7, press  button (UP) or  button (DOWN) for selection.

C12 parameter definition table:


C12 value	Minimum Voltage(V)		
	24V Controller	36V Controller	48V Controller
0	Default value-2V	Default value-2V	Default value-2V
1	Default value-1.5V	Default value-1.5V	Default value-1.5V
2	Default value-1V	Default value-1V	Default value-1V
3	Default value-0.5V	Default value-0.5V	Default value-0.5V
4	<b>Default value 20V</b>	<b>Default value 30V</b>	<b>Default value 40V</b>
5	Default value+0.5V	Default value+0.5V	Default value+0.5V
6	Default value+1V	Default value+1V	Default value+1V
7	Default value+1.5V	Default value+1.5V	Default value+1.5V

C12 default value is 4, namely, controller minimum operating voltage (voltage shortage value); when setting is 5, the default value plus 0.5V, when setting is 4, the



default value minus 0.5V and so on.

After finishing C12 parameter setting, press  button (SW) to return to parameter setting interface.

#### ○ C13 ABS brakes of the controller and parameters of anti-charge control Setting

Under parameter setting interface, move cursor to C13 and press  button shortly (SW), and the value flashes.

C4 : 0
C5 : 10
C6 : 3
C7 : 0
C8 : 0
C9 : 0
C10 : N
C11 : 0
C12 : 4
▶C13 : 0
C14 : 2
NEXT ▶

C13 is ABS brakes of the controller and parameters of anti-charge control setting, the default value is 0 with the setting range between 0-5, press  (UP) button or  (DOWN) button to make selection.


C13 parameter definition table:

C13 Value	ABS braking strength	Energy recovery efficiency
0	None	None
1	Class 1 braking strength	Best energy recovery efficiency
2	Class2 braking strength	General energy recovery efficiency
3	Class 3 braking strength	Weaker energy recovery efficiency
4	Class4 braking strength	Poor energy recovery efficiency
5	Class5 braking strength	Bad energy recovery efficiency


The recommended value of C13 is 1; other values need to be chosen with caution for use.


**Be sure to note:**



- 1.the higher is the braking intensity level, and the braking strength will be greater, the greater damage to the motor shaft accordingly.
2. If the battery has a BMS function, disable this function.

After finishing C13 parameter setting, press  button (SW) to return to parameter setting interface.

○ **C14 Power-assist tuning parameters Setting**


Under parameter setting interface, move cursor to C14 and press  button shortly (SW), and the value flashes.





C14 is the parameters of power-assist tuning setting, with the default value of 2. The power-assist is between 1-4 gear, and it is invalid until P3 equals to 1. The setting range 1-3, and press  (UP) button or  (DOWN) button for short to make selection.

C14 parameter definition table:

C14 Value	Assist strength of intelligent pedal motor
1	Weak assist strength of motor
2	General assist strength of motor
3	Stronger assist strength of motor

After finishing C14 parameter setting, hold  button (SW) shortly to save the current set values and enter C15 parameter setting interface.



○ **C15 Push-assist Speed Parameters Setting**

Enter C15 parameters setting interface, C15 flashes. C15 is the setting of push-assist speed, default value is 6, range from 4-6, press  (UP) button or  (DOWN) button to choose.




### C15 parameters

C15valte	Push-assist speed
4	4Km/H
5	5Km/H
6	6Km/H

After finishing C15 parameter setting, hold  button (SW) shortly to save current set values and enter C1 parameter setting interface again. Or hold  button (SW) long for about 2 seconds to exit C parameter setting environment and return to the display 1.

## L Parameter Setting

### ○ L1 Parameter setting

Under parameter setting interface, move cursor to L1 and press  button shortly (SW), the value flashes.

L1 parameters are applicable to the automatic under-voltage controller. The default of the factory is 0.

When L1=0, the automatic under-voltage controller can automatically select the under-voltage value according to the battery voltage.


When L1=1, the under-voltage value of the automatic under-voltage controller is forced to be 20V.

When L1 = 2, the under-voltage value of the automatic under-voltage controller is


forced to be 30V.

When  $L1 = 3$ , the under-voltage value of the automatic under-voltage controller is forced to be 40V.



After finishing L1 parameter setting, press  button (SW) to save the current value and then enter L2 parameter setting interface.

#### ○ L2 Parameter setting

Under parameter setting interface, move cursor to L2 and press  button shortly (SW), the value flashes.


L2 parameter is suitable for the super high-speed motor controller. The default of the factory is 0.

L2 parameter will be activated when the value of P1 parameter exceeds 255. L2 parameter should use in combination with P1.


When  $L2=0$ , P1 parameter is set as the calculated value.

When  $L2=1$ , P1 parameter is set as a half of the calculated value.



After finishing L2 parameter setting, press  button (SW) to return to parameter setting interface.

#### ○ L3 Parameter setting


Under parameter setting interface, move cursor to L3 and press  button shortly (SW), the value flashes.

L3 parameter is applicable to the dual mode controller. The default of the factory is 1.


When L3=0, the controller will activate No-Hall model only when the Hall sensor in the motor fails

When L3=1, the controller will choose the proper model to use according to the controller system optimization.



After finishing L3 parameter setting, press  button (SW) to return to parameter setting interface.

#### ○ L4 parameter setting

Under parameter setting interface, move cursor to L4 and press  button shortly

(SW), the value flashes.

L4 parameter is used to adjust the delay time of automatic shutdown of the LCD, the default value is 5, and the range of adjust is 5-120 minutes.

When L4=5, the delay time is 5 minutes.


When L4=6, the delay time is 6 minutes.

When L4=7, the delay time is 7 minutes.


.....

When L4=120, the delay time is 120 minutes.



After finishing L4 parameter setting, press  button (SW) to return to parameter setting interface.

### ○ Exit Parameter Setting


After each setting, the meter will exit parameter setting interface and return to display 1, If hold  button (SW) for about 2seconds.

Under each parameter setting interface, if there's no button operation on the meter for more than 1 minute, and then the meter will automatically return to display 1, and the original parameters will be saved.


### Parameter Copy

Set parameters (include general project parameter, P parameter and C parameter) of all KT-INS01 meter produced by our company according to requirements, and set the meter to be a data source according to the method of "C11 meter attribute selection setting". Use special wiring cables to properly wire to KT-INS01 meter needs to be copied




according to the diagram.



Meter parameter copy wiring diagram



Special wiring cable

Turn on meter power supply of data source. Power supply of 48V or 36V or 24V is available (VB + positive power supply). After wiring the meter needs to be copied, hold  button long till meter is startup. Within 5 seconds after startup, hold  button (UP) and  button (DOWN) simultaneously for about 2 seconds, meter parameter copy is completed. If the copy operation is correct, the meter subject to be copied will display as follow.



Copy end !

**Please note:** Both C9 power-on password and C11 meter attributes can't be copied. Besides, KT-INS01 meter can only copy parameter of the same meter model.

### User Setting Note

After entering the user setting environment, if there's no button operation on the data for more than 1 minute, the meter will automatically return to display1, and the new set parameters won't be saved.

The factory parameter set value and the default value of the meter can be set according to user requirements, the meter parameter can be restored by using "**C10 automatically restore factory setting**" approach when adjusting it.

All parameter functions for special controller and torque controller are according to the results of real-testing.

### Version Information

KT\_INS01\_V1.0

Released on October 7,2025